



Special instructions for Sporttraxx Timekeeper

A special ON/OFF button has been added to the clock in order to totally isolate the internal battery. It is used for long term storage and shipping on airways.



Once the button is in OFF position, the clock, the modem and the beam Led will not work.

Attention: turning off the clock with this button is cancelling the synchronization of the rally time, and the clock needs to be synchronized again, either manually, via computer or via a master clock.

Synchronization

Manual

1. Turn on the clock using STOP – MENU – ENTER in sequence
2. Press MENU till you reach the Password request
3. Insert Password, then press ENTER
4. Press MENU till you reach Menu 23. Set Time
5. Insert the actual time + 10 seconds and wait
6. When you reach the actual time, press ENTER to synchronize the clock
7. Press STOP to return to normal time view

Computer

1. Install the Sporttraxx Set Clock software

2. Start software
3. Synchronize the PC clock to Internet time
4. Connect serial cable to PC USB port and Serial port on the clock
5. Turn on the clock using STOP – MENU – ENTER in sequence
6. Press MENU once. Battery level is shown
7. Select the Set Time button to synchronize the time
8. Select the Clear times to clear the memory of the clock
9. Select a SS number, the time resolution, the working mode of the clock
10. Each completed action is confirmed by a different melody
11. Disconnect cable and press STOP to return to normal operation of the clock

Master Clock

1. Connect the serial cable to clock and Master Clock
2. Turn on the clocks using STOP – MENU – ENTER in sequence
3. On Master clock press MENU once. Battery level is shown
4. Press 2. The display will show: “Press 2 to Synch”
5. On clock to be set, press MENU once. Battery level is shown
6. Press 2 on master clock
7. The clock to be set will be synchronized, followed by a melody
8. Disconnect cable and press STOP to return to normal operation of the clock